



Save Time. Money. Materials. And Sweat.

Introducing the **CHENG Pro-Form Mold Making System**—the latest innovation from CHENG Concrete that makes forming a concrete countertop radically easy, efficient, and more environmentally friendly! Craft a high quality, professional-grade concrete countertop mold in minutes—**reducing time, expense, and carbon footprints.**

Put away your saws and drills. Save the money and time spent on melamine, plywood and screws. With the CHENG Pro-Form Mold Making System, you never drill or cut into the mold base, making it possible to reuse the same surface for several or more project pours. This innovation will reduce your waste, enable you to reuse materials, lower your costs and increase your margins—without sacrificing the quality or finish of the concrete surface.

When you use the CHENG Pro-Form Mold Making System in lieu of standard melamine and particle board to create a concrete countertop, you dramatically reduce waste. Reducing materials and waste means reducing energy use and resources needed to ship and dispose of these materials, lessening the carbon footprint of a given concrete countertop project.

Each Kit Includes:

- 16 – 48" Pro-Form Wall Sections
- 8 – 96" Pro-Form Wall Liners
- 1 – 75' Roll of Double sided Fiberglass Tape
- 2 – 108' Rolls of 1/2" Transfer Tape

Additional Items Required:

- Transfer Tape Application Gun (sold separately)
- Box Cutter or Utility Knife
- Mold Base (1/2 " Melamine or comparable)

Instructions for Use



1. Before starting, remove all dust, oils, grease or water from the surface of mold base. Following the perimeter of the template, apply the fiberglass tape to the mold base and insure the tape is firmly adhered to the mold base.



2. Remove protective paper strip exposing the double sided adhesive fiberglass tape. Take precautions to prevent dust or dirt from coming in contact with adhesive surfaces of the fiberglass tape.



3. Apply Cheng Pro-Form wall sections onto the fiberglass tape. Follow the perimeter of the template and insure the wall section is firmly adhered to the double sided fiberglass tape.



4. Apply additional Cheng Pro-Form wall sections. Fit each wall section against the previously placed wall sections and be sure to align the wall sections flush with each other.

5. After placement of all Pro-Form wall sections, cut the Pro-Form wall liner to exact length and apply two strips of transfer tape to the back side of each wall liner section using the transfer tape applicator.



Transfer Tape and Applicator



Apply transfer tape to top and bottom of wall liner



6. Firmly apply the wall liner to the wall section.

7. Complete the mold by sealing with 100% silicone caulk.



Apply silicone to all corners in the mold.



Tooling the silicone with a fillet tool.

8. After the caulk is dried, your mold will be ready to pour into.